

lovair

Air Fury Cleaning & Maintenance

The minimum cleaning period for the dryer is every 3 months. Details are shown below:



Isolate the unit from the electricity supply before servicing/cleaning.

Remove the cover by unscrewing the fixing bolts at the bottom face of the dryer.

Remove dust, fluff and build up of other foreign matter from the inlet and outlet grill areas on both the inside and outside of the cover. Where necessary, use a brush around the internal air outlet and inlet areas.

The cover can be wiped with a damp cloth and mild cleaning solution. Do not soak. Never use abrasives to clean the cover.

WARNING

THE HAND DRYER CONTAINS LIVE TERMINALS (230V), SO THE COVER MUST NEVER BE REMOVED WITH THE POWER SUPPLY ON. IF IN DOUBT, CONSULT AN ELECTRICIAN.

Troubleshooting

Problem	Indicator	Cause	Solution
Dryer runs constantly	Motor does not switch off	Object too close to sensor	Remove object from within sensor range (for example dryer is mounted too close to a surface below the sensor)
Dryer does not run	LED does not illuminate	No power to hand dryer	Check power supply to dryer
	LED changes colour, but motor does not run	Carbon brushes in motor have worn down	Replace carbon brushes
	LED does not change colour	PCB has failed	Replace PCB module
Sensor only appears to detect objects at close range	Dryer will not operate with hands at normal distance from sensor	Sensor lens may be obscured	Clean sensor lens
Dryer runs, but air flow is cold	Air stream is cold	Heater element has failed	Replace heater element
Dryer runs, but has no power to air flow	Motor runs slowly	Carbon brushes in motor have worn down	Replace carbon brushes
	Motor runs fast, but lack of air flow	Air outlet nozzle is blocked	Clear obstruction from outlet

Warranty Summary

- 12 Months parts and labour (This does not cover wearing items such as carbon brushes)
- Additional 4 year parts only (This does not cover wearing items such as carbon brushes)
- Warranty only covers defective parts, and not fair wear and tear
- Lovair are given reasonable opportunity to repair or replace the faulty product or part
- Motor brushes not covered under warranty as they are a wearing part
- It is Lovair's decision to repair or replace a product or component