

TO CONVERT 40100 OR 40101 CONTROL TO 40102 MICRO CONTROL

Conversion Kit Contains

New control 40102
New Wire (1)
New Schematic for cover

IMPORTANT: MAKE SURE POWER SUPPLYING DRYER IS DISCONNECTED BEFORE SERVICING.

1. **Disconnect power to unit.** Remove cover of unit by removing tamper-proof bolts.
2. Remove 2 screws holding the control assembly bracket (Fig. 1A) and 2 screws holding the sensor bracket (Fig. 1B) and save the screws.
3. Disconnect 4 wires leading to control assembly and 2 green ground wires from bracket.
4. Remove the white wire (see Fig.1C) from the terminal block (marked "N") and replace with the 20" white wire supplied with 2 (.250") terminals. (Pliers will help with removal)
5. Install new control and sensor using screws that held the old control and sensor (Fig. 2A & B)
6. Connect the wires using Fig. 2 and the new schematic as a guide (tuck excess behind the bracket)
7. Replace dryer schematic sticker on cover with new schematic supplied and reinstall cover.

